

# PRETORIA

We Design Innovative Bus Interiors

Transit Interiors, Inc.  
1975 Joe B. Jackson Pkwy  
Murfreesboro, TN 37127

Tel. (615) 867-8515  
Fax (615) 867-8790  
[www.PretoriaUSA.com](http://www.PretoriaUSA.com)

## BALLAST TECHNICAL SPECIFICATION

<b>Ballast Model</b>	<b>BAL-027-XX</b>
<b>Last Spec Sheet Update</b>	12/5/20006
<b>General Description</b>	24Vdc (nominal) <u>Standard</u> electronic ballast for 1 lamp equipped with status indicating LED's
<b>Starting Mode</b>	Instant Start
<b>Lamp(s) per Ballast</b>	1
<b>Lamp(s) Compatibility</b>	F24T12, F36T12, F48T12, F60T12, F72T12
<b>Output Efficiency</b>	Minimum of 80% of full lamp output
<b>Minimum Input Voltage</b>	22Vdc
<b>Normal Input Voltage</b>	28Vdc
<b>Maximum Input Voltage</b>	30Vdc
<b>Output Current</b>	200mA @ 28V Input
<b>Operating Temperature Range</b>	-4° F to 131° F / (-20° C to 55° C)
<b>Maximum Current Draw</b>	1.6A (F72T12)
<b>Maximum Output Power</b>	50 Watt
<b>Output Frequency</b>	65 kHz +/- 5kHz
<b>Transients and Over Voltage Protection</b>	40Vdc
<b>Over Temperature Protection</b>	Integrated PTC Fuse
<b>Reverse Polarity Protection</b>	Integrated PTC Fuse
<b>Output Short Circuit: 24 Vdc</b>	210mA
<b>Short Circuit Protection</b>	30 msec. shutdown with auto restart at tempoary loss of contact
<b>UL 935 Type CC</b>	Yes
<b>FCC Part 18</b>	Yes
<b>Environmental Protection</b>	Conformal coating against air pollution, moisture and humidity
<b>Green LED Indicator</b>	Green LED on indicates that the ballast is functioning properly
<b>Red LED Indicator</b>	Red LED on indicates a ballast malfunction
<b>Other Features</b>	5 year warranty, non potted, fire proof (steel or aluminum) housing, repairable, recyclable, radio frequency shielded.

### BAL-025

BAL-025 meets the requirements for UL935 Type CC; Test Purpose: To determine that the ballast will not cause a harmful arc.

BAL-025 incorporates a PTC (Positive Temperature Coefficient Resettable fuse) which provides protection for:

Reverse polarity - After correcting polarity, ballast will operate.

Over temperature - At 230 degrees F, the PTC fuse will trip. After cooling off, the input power needs to be re-applied for start.

Specifications are subject to change without notice

Transit Interiors, Inc.  
1975 Joe B. Jackson Pkwy  
Murfreesboro, TN 37127

Tel. (615) 867-8515  
Fax (615) 867-8790  
[www.PretoriaUSA.com](http://www.PretoriaUSA.com)

## BALLAST TECHNICAL SPECIFICATION

### INPUT CURRENT TABLE

Model / Lamp	F24T12	F36T12	F48T12	F60T12	F72T12
BAL-027	.55A	.70A	.75A	1.25A	1.40A

### BALLAST DIAGNOSIS AND LED INDICATORS

Model	Condition	Red LED	Green LED	Operation
BAL-027	Normal	OFF	ON	N/A
	Malfunction	ON	OFF	Turn off power and wait 5 seconds. Restart ballast. If Red LED is still on, replace the ballast.